


WASHER/DRYER CONTROL PANEL PARTS

Whirlpool

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)

WASHER/DRYER
LAUNDRY SYSTEM




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3405971	Literature Parts Installation Instructions	7	692993	End Cap, Console (L.H. & R.H.)	23	3977194	Panel, Control White
2	LIT3401098	Use & Care Guide	8	348689	Screw, 8-18 x 3/4	24	3977193	Almond
2	LIT3952875	Wiring Diagram	9	694091	Screw, 8-18 x 3/8	24	3977195	Biscuit
2	LIT3954147	Energy Guide	10	3362987	Switch, Water Level	25	3406143	Knob, Timer (Dryer) White
2A	3406288	Harness, Console Wiring (Automatic) (Includes Illus. 2A, 2B & 2C)	12	8054142	Switch, Water Temperature	25	3406144	Almond
2B	3350130	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)	13	693711	Sleeve, Console Lock Screw (2)	25	3978872	Biscuit
2B	696073	Receptacle, Connector (Connects With Lower Automatic Harness)	14	693151	Spring, Console Lock (2)	25	3406133	Knob, Push-To-Start White
2C	3948614	Disconnect Block (Connects With Automatic Timer)	15	3400860	Screw, Console Lock (2)	25	3406134	Almond
5	3952499	Timer, Control (60 Hz.) (Automatic Washer)	16	3406720	Timer, Control (60 Hz.) (Dryer) (Timer Motor Not Serviceable)	25	3978871	Biscuit
6	8054285	Bracket, Control	18	3395382	Switch, Push-To-Start	27	3950759	Knob, Control (2) White
			19	693152	Bumper, Console (5)	27	3950760	Almond
			20	96435	Screw, Timer Mounting (2)	27	3978873	Biscuit
			21	694037	Clip, Console	28	3950762	Dial, Timer (Washer) White
			22	3390646	Screw, Dryer Timer Mounting (2) (8-18 x 5/16)	28	3950763	Almond
						29	3978870	Biscuit
						29	3951026	Knob, Timer (Washer) White
						29	3951027	Almond
						31	3978869	Biscuit
						32	692983	Lock, Console (2)
							694419	Buzzer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3406108	Door Switch	7	348205	Door, Front	13	343641	Screw, 10-16 x 1/2
2	697773	Screw, 6-20 x 7/8		689314	White	14	3389441	Catch, Door
4		Panel, Front		3978598	Almond	15		Handle, Door
	692619	White	9	349462	Biscuit	686711		
	692620	Almond	10	685203	Bearing & Seal	689308		
	3978587	Biscuit			Clip, Felt	3978592		
5	3390734	Seal, Door	11	696144	Pad (2)	16	692846	Support Protector
6	695656	Door, Rear	12	3390663	Strike, Panel	19	694091	Screw, 8-18 x 3/8
					Screw, 10-16 x 1/2	20	348023	Hinge & Pin, Door (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)	21	8066051	Pulley, Motor (60 Hz.)	31		Closure, Control Area
2	8066068	Motor, Main Drive (60 Hz.)	22	3394332	Idler & Slide Assembly	692781	White	
3	3405028	Clip	23	692771	Nut, Idler Bracket To Base	692782	Almond	
5	696541	Bracket, Motor	24	3399633	Base, Dryer	3978599	Biscuit	
6	3390405	Panel, Rear	25	692400	Nut, Push-In	32	354975	Screw & Washer (3) (Lid Latch Mounting)
7	343641	Screw, 10-16 x 1/2	26	692926	Cove, Transition Panel (Black)	33	693304	Screw & Washer (2) (Transition Panel To Closure)
8	3394228	Cover, Terminal Block	27		Panel, Transition	34	697776	Screw, Ground (10-32 x 5/8)
10		Panel, Side (L.H.)		692933	White	35	3390631	Screw, 10-16 x 3/8
	3402293	White		692934	Almond	36	661606	Capacitor, Motor Start (Automatic Washer)
	3402294	Almond	28	3978591	Biscuit	37	357030	Clamp, Capacitor
14	3399602	Elbow, Upper	29	692641	Top, Dryer Panel, Side (R.H.)	38	343641	Screw, Capacitor Mounting
15	3394083	Clip, Front Panel (2)		3402287	White	41	686770	Edge, Protector
16	98234	Clip, Ground		3402288	Almond	44	90296	Clip
17	3399603	Elbow, Lower		3978590	Biscuit			
20	8066064	Belt, Drive	30	693145	Latch, Lid			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)



DRYER BULKHEAD PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, 10-16 x 1/2	27	697540	Bulkhead	37	693141	Clip, Wiring Harness (3)
2	3395396	Clip, Air Duct To Bulkhead	28	348399	Lint Screen	38	694018	Cord, Power
3	696529	Air Duct & Cover	29	685273	Cover, Lint Screen Outlet	38a	694415	Strain Relief, Power Cord
5	3398128	Thermostat, Internal Bias	30	690997	Tri-Ring (4)	40	3388703	Washer, Support
8	3403140	Thermostat, Heater Box 205°F (96C)	31	3399506	Shaft, Drum Roller (L.H.)	41	279393	Screw Kit (For Terminal Block)
9	489463	Screw, 8-18 x 5/8	32	3397588	Roller, Support (2)	42	279318	Terminal, Tinned & Brass (3) (Includes Illus. 41)
10	3398161	Clip, Heater Box To Bulkhead	33	348197	Washer, Support (4)	43	697776	Screw, 10-32 x 1/2
11	697269	Heater Box	34	3359452	Nut, 3/8-16 (2)	44	3390647	Screw, 8-18 x 1/2
13	339956	Seal, Air Duct To Bulkhead	35	3390631	Screw, 10-16 x 3/8	46	90767	Screw, 8-18 X 3/8
14	696426	Wheel, Blower	36	3396657	Harness, Main Dryer Wiring (Includes Illus. 36A, 36B, 36C, 36D & 36E)	47	3392519	Fuse, Thermal
16	8066094	Seal, Fan Scroll	36A	717252	Receptacle, Terminal (2-Way) (Connects With Door Switch Harness)	48	359702	Cap, Screw
17	696418	Fan Scroll	36B	697780	Receptacle, (Gas Valve)	49	255563	Clip, Strain Relief
21	3399507	Shaft, Drum Roller (R.H.)	36D	3395683	Receptacle, Multi-Terminal (Connects With Dryer Motor)	51	8066086	Drum, Hole Plug
22	695943	Drum, Dryer				52	345335	Cover, Manifold
23	3394508	Ring, Bearing				53	347455	Support, Heater Box
24	685207	Baffle, Drum (3)				54	3387208	Support, Corner Gas
25	97787	Screw, 11-16 x 7/8				55	697571	Guard, Sock
26	345648	Seal, Drum Rear				56	3402856	Burner (Refer to page 19 For Complete Breakdown)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER SUPPORT AND WASHER PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




Illus.	Part No.	DESCRIPTION
1	694304	Cover, Channel
2	692647	Support, Dryer (L.H.)
3	343641	Screw, 10-16 x 1/2
4	3400000	Screw, 10-24 x 3/8 (8) (Washer Cabinet To Dryer Supports)
5	692646	Support, Dryer (R.H.)
6	3954108	Harness, Lower (Automatic) (Includes Illus. 6A, 6B & 6C)
6A	696074	Plug, Terminal (12-Way) (Connects With Automatic Console Harness)
6B	62889	Plug, Terminal (3-Way) (Connects With Automatic Lid Switch Harness)
6C	62505	Block, Disconnect (Connects With Automatic Washer Motor)
7	3347812	Clip, Wiring Harness (4)
8	8066080	Hose, Pressure Switch
11	90016	Clip, Pressure Switch Hose (2)
12	693141	Clip, Harness

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER TOP AND LID PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
3	3398843	Lid White	12	384693	Top White	16	358684	Strike, Lid Switch
	3398844	Almond		384694	Almond	17	384459	Hinge, Lid (R.H.)
	3398847	Biscuit		3978593	Biscuit	18	3400030	Screw, 10-24 x 1/2
4	384475	Bumper, Lid (2)	13	19119	Bumper, Lid Hinge (2)	20	3400901	Nut, Ground Screw
5	384458	Hinge, Lid (L.H.)	14	21258	Bearing, Lid Hinge (2)	22	3355806	Switch, Lid 90016 Clip, Harness
7	3351355	Screw, Lid Hinge Mounting (4)	15	3356311	Screw & Washer, Lid Switch Shield (2)	23		Routing
9	692985	Clip, Spring (2) (Top To Cabinet)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	356746	Clip, Condenser
2	343641	Screw, 10-16 x 1/2
3	62863	Screw, Mixing Valve Mounting
5	3360389	Valve, Water Mixing
6	370451	Clamp, Hose
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8		Cabinet
	696013	White
	696014	Almond
	3978594	Biscuit
9	3390046	Protector, Edge
10	696710	Hose, Drain
11	692400	Nut, Push-In (2)
12	660975	Plug, Top To Cabinet
13	356739	Connector, Hose
14	370445	Clamp, Hose
15	356471	Cap, Siphon Break
16	356363	Siphon Break
17	272861	Clamp, Hose
18	696394	Hose, Water Inlet (Siphon Break To Tub Ring)
19	367594	Foot, Front (2)
20	358594	Foot, Rear (2)
22	3394083	Clip, Front Panel
23	358652	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27		Panel, Front
	692628	White
	692629	Almond
	3978596	Biscuit
31	3350013	Foam (2)
32	64247	Screw, 10-16 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete) (Refer To Page 16 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951312	Clutch (Complete)
6	3951308	Band and Lining (Includes Illus. 7 & 8)
7	3946846	Spring & Damper Assembly
8	62646	Cap, Clutch Spring (2)
9	3360630	Gearcase (Complete)(Refer To Page 15 For Further Breakdown)


Illus.	Part	No.	DESCRIPTION
10	3357334		Screw, (Gearcase To Tub Support)
11	62611		Plate, Motor Mount To Gearcase
13	3364003		Coupling, Motor & Isolating
14	661600		Motor, Main Drive
15	3355454		Clip (Anti-Rattle)
16	3946532		Plate, Motor
18	3363394		Pump, Complete
19	62700		Retainer, Pump
20	62850		Switch, Main Drive Motor
21	62691		Grommet, Motor (4)
22	3349637		Retainer, Motor (2)
24	3387485		Screw, 10-16 x 5/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	285203	Centerpost Bearing Kit (Incls. Illus. 10, 11, & 12)
3	64137	Shield, Tub
4	388492	Spring, Counterweight
5	3406201	Suspension Assembly (3)
6	63755	Base
10	356934	Seal, Centerpost
11	3347047	Centerpost Bearing, Centerpost (2)
12	357409	Seal, Centerpost
13	63134	Ring, Sound Deadening
14	343641	Screw, 10-16 x 1/2
15	63636	Bracket, Counterweight Spring
17	63637	Shield, Tub
18	3351021	Nut, 1/2 - 13 (1)
19	63740	Tub Support and Drum
22	90767	Screw, 8-18 x 3/8
23	386011	Screw & Washer (Base To Cabinet)
24	696044	Block, Restraint

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND BASKET PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
3	63840	Filter, Agitator
4	3349098	Agitator
5	64175	Tub Ring & Gasket (Includes Illus. 7, 14 & 15)
6	21366	Nut, Spanner
7	3359587	Gasket, Tub Ring
8	3351985	Basket
9	8066081	Tub
10	389140	Block, Basket Drive
11	3949550	Washer
12	371502	Clamp, Hose
13	386929	Hose, Tub To Pump
14	352155	Clip, Retaining
15	356398	Tube, Drain Off
16	357640	Screw & Washer (Tub Mounting)
17	383727	Gasket, Centerpost

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER WATER SYSTEM PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




WS900B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)



Illus.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
20	285352	Seal, Thrust Plug
21	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
22	3362552	Ring, Retaining
23	285735	Washer Kit, Thrust
24	62570	Gear, Spin Neutral Assembly
25	388253	Rack, Connecting
26	3349296	Actuator, Shift
27	62621	Washer, Intermediate
28	388815	
29		


GC-215C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




BD-313B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SALES ACCESSORY PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)




Illus.	Part No.	DESCRIPTION
1	279823	Side Exhaust Extension Kit (Complete)
2	488729	Screw
3	3395536	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2
 (Designer White) (Designer Almond) (Biscuit)



OPTIONAL PARTS (NOT INCLUDED)

ILLUS. NO. PART NO. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
 72107 Almond
 4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
 350930 White
 350956 Almond
 4392901 Biscuit

ILLUS. NO. PART NO. DESCRIPTION

PAINT, BULK (1 qt.)

799344 White (Uncut)
 978883 Almond (Uncut)
 4392900 Biscuit (Uncut)

ACCESSORY PARTS

Plug, Dryer Side Panel
 692790 White
 692791 Almond
 3977784 Biscuit

OIL

350572 Oil, Gearcase (16 Oz.)

ILLUS. NO. PART NO. DESCRIPTION

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER


285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

3402856 BURNER ASSEMBLY

For Models: LTG5243DQ2, LTG5243DZ2, LTG5243DT2

(Designer White) (Designer Almond) (Biscuit)

**USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3402856	Burner Assembly 60 Hz.	9	694421	Screw, 8-32	22	3406051	Elbow Union Assembly
2	697408	Base, Burner	10	694538	Bracket, Shunt	23	3388638	Nipple, Short
3	3401777	Valve, 60 Hz.	11	694422	Spring, Regulator	24	3391118	Supply Line (Gas)
4	234822	Orifice	12	239822	Pipe, Plug	25	233076	Nut
	347743	Natural Gas	13	694423	Screw	26	3393767	Pipe
5	3401849	L.P. Gas	15	3392268	Burner			
6	694539	Harness	16	3387057	Screw, 8-18 X 3/8			
7	694540	Coil, 60 Hz. (Split)	17	686590	Ignitor			
8	694424	Coil, 60 Hz.	18	3393909	Screw and Washer 8-32 x 1			
		Leak Limiter	20	697409	Bracket, Sensor	49573		Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.
			21	338906	Sensor, Radiant			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST